

Transformer: 100 Volt line


Primary nominal tappings:

1:2 30,0W 2:3 15,5W 3:4 7,5W 1:3 5,5W 2:4 2,7W 1:4 2,0W

1 = Red, 2 = Yellow, 3 = Green, 4 = Blue

Black: White 8 ohm

1W/1m Pink Noise 1/3 octave bands



Installation, Operation and Maintenance Procedures

- How to mount the loudspeaker:
 - -Lamp-version (L): Ensure that the cable is fastened securely to the ceiling.
 - -Bracket-version (LB): Screw the bracket to wall or ceiling with screws.
 - -Swivel bracket version (LS): Read mounting instructions on carton box.
- To change the position of the loudspeaker:
 - -Bracket version (LB): Adjust the bracket (by loosening / tightening the screws) as required.
 - -Swivel bracket version (LS): Adjust the swivel base (by loosening / tightening the screws) as required.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Take care when loudspeaker is energized (100V).
- This loudspeaker is supplied with a 2 year warranty against defective workmanship.

Most of our products are available in different colours, impedances and power ratings.



DNH reserves the right to alter specifications without notice.